



Supplement to Yanmar Kit Installation Instructions

SAFETY


This product is designed and intended only for use with a YANMAR engine. All safety and warning information contained in the Yanmar Operation Manual and Service Manual is adopted and incorporated to apply to the components, accessories, and parts that are utilized with Yanmar engines. Follow all instructions and precautions before installing this product, before operating, during operation, and during periodic maintenance procedures for your safety, the safety of others, and to protect the performance of your engine.



YANMAR CO., LTD.
YANMAR AMERICA CORP.

Item	Part No.	Description	Quantity	Remarks
1	900400	Main Harness Assembly	1	
2	198461-52950	Relay for EGR valve	1	Included w/ engine
3	-	80A, 12V Relay	2	Included w/ harness
4	-	Starter Sub Harness	1	Included w/ harness

MODELS
4TNV88C
4TNV98C
4TNV98CT



NOTE: Starter Sub Harness may not be necessary; Starter type will determine

KPH9 - Harness KIT
INS-KPH9-0010



Installation Instructions

NOTE: Only the Starter and Glow Plug Relays are included with the harness kit. The EGR valve relay is supplied with the distributor standard specification engine in the loose parts box. The optional connections for distributor use are located in the Accessory Coupler. The optional features include Pre-Heat Lamp, Engine Stop 1 & 2, Charge Lamp, etc.

Please see the next page for detailed installation instructions.

WARNING: Be sure battery cables are connected correctly. Disconnecting either the positive or negative battery cable while the equipment is operating will cause premature failure of electronic components. Also, never weld on equipment with the ECU connected to the wire harness.

NOTE: In the event that the wire harness needs to be extended, never use scotch locks or butt connectors to extend the wire harness. All extended wires must be soldered and sealed.

Remote Mounted ECU Applications:

For applications that remotely mount the ECU within the wire harnesses reach please use the following ECU mounting guidelines:

- 1- Install the ECU in a location that is not subject to steam or high-pressure water for cleaning
- 2- Install the ECU in a location that is well ventilated and not subject to direct sunlight.
- 3- Install the ECU so that the connector faces downward. Failure to do so may trap water in the connector, resulting in corrosion of connector pins.
- 4- Ensure no water is trapped inside the connector when plugging the connector. Water inside the connector may corrode connector pins, resulting in malfunctioning of the ECU.

Refer to harness drawing for additional design requirements for consideration of application. A troubleshooting guide is available through Yanmar's Distributor Website or by contacting Yanmar America's Service Department.


Table 1: Comply with torque standards in the table to avoid unexpected damage during installation or in the future.

Diameter x Pitch	Kgf-m	Foot-lbf	N-m
M5x0.8	0.4 ~ 0.7	3 ~ 5	4 ~ 6.7
M6 x 1.0	1.0~1.2	7 ~ 9	9.8 ~ 11.8
M8 x 1.25	1.5 ~ 2.9	10.6 ~ 20.9	14.4 ~ 28.3
M12 x 1.75	8.0 ~ 10.0	57.8 ~ 72.3	78.4 ~ 98.0

Note: There are no bolts included with harness kit


Harness Routing Instructions

1. Lay the loose harness on engine to gauge fitment and placement of where the relays, ECU, and connectors should go based on the wiring diagrams provided. Please refer to TNV application manual for cautionary measures to be taken when mounting a harness to an engine.
2. Secure section of loom containing (2) P-clips to the flywheel housing with loosely attached P-clips. There will be a series of M10 bolt holes on the top of the flywheel housing.



P-clips hold down the alternator and starter section of loom to the flywheel housing. Make sure P-clips and loom have the proper orientation to allow the loom to rest close to the flywheel barrel.

3. Connect alternator plugs (51) & (53) and starter connectors (56) & (58). Cover terminals after connecting.



Replace terminal covers after connecting


Starter Sub Harness may need to be removed to properly attach connector (58)

4. Layout harness as shown. Connectors 1, 2, 64, 65 - 66, 44, 48, 101 - 104, and the battery leads (49 & 50)



Harness Routing Instructions

- The intermediate couplers (36-39) should be connected next. The mounting points for the turbo engines may differ from the naturally aspirated engines. Please see the pictures below for reference on exact positioning (4TNV88C shown below). Connect glow plug (30) and oil pressure switch (25). Route the DPF loom section similar to placement shown. Use loose clamp noted to attach harness. Always avoid harness contact with high temp surfaces such as the DPF, EGR, etc.




Oil Pressure Switch and Glow Plug

Intermediate couplers (36 - 39)

Loose clamp for fixing DPF harness section


DPF harness section continued below

- Route the DPF branch between the EGR valve and the fuel filter up to the DPF connections. Check and adjust if necessary to ensure that no contact will be made in operation between harness and high temp surfaces (DPF, etc)



The routing shown is for exhaust manifold mounted DPF's. Flywheel mounted DPF's will need harness section routed similarly. This section is secured by clamp shown above.

Refer to harness drawing for additional design requirements for consideration of application.



ハネスの取出し方向は図の通りとする。
THE DIRECTION OF TAKING OUT THE HARNESS IS SHOWN IN FIGURE.


REMARKS
WIRING DIAGRAM IS E3-29C88-1020

No.	線路 KIND	線色 COLOR	回路記号 CIRCUIT	端子 TERMINAL	回路記号 CIRCUIT	端子 TERMINAL	回路記号 CIRCUIT	端子 TERMINAL	備考 REMARKS
001	AVS	5.0	R	B60	B60	B5C			
002	AVS	5.0	R	B60A	B60A	B5C			
003	AVS	5.0	R	B60B	B60B	B5C			
004	AVS	5.0	R	B01	B01	B5C			
005	AVSS	1.25	R	B01A	B01A	B5C			
006	AVSS	1.25	R	B02	B02	B5R			
007	AVSS	2.0	R	K01	K01	3			
008	AVSS	2.0	R	K03	K03	3			
009	AVSS	2.0	R	K05	K05	3			
010	AVSS	2.0	R	B63	B63	B5A			
011	AVSS	1.25	R	K68	K68	32			
012	AVSS	0.85	R	K69	K69	32			
013	AVSS	0.5	R	K88B	K88B	101			
014	AVSS	0.5	R	K35	K35	101			
015	AVS	8.0	R	B45	B45	4			
016	AVSS	2.0	R	K02	K02	1			
017	AVSS	2.0	R	K04	K04	1			
018	AVSS	2.0	R	K06	K06	1			
019	AVSS	1.25	R	B00	B00	4			
020	AVSS	1.25	R	B00A	B00A	4			
021	AVSS	1.25	R	B00B	B00B	4			
022	AVSS	1.25	R	B00C	B00C	1			
023	AVSS	0.5	R	B00D	B00D	1			
024	AVSS	0.5	R	B00E	B00E	1			
025	AV	8.0	W	B59	B59	56			
026	AV	8.0	W	B59A	B59A	56			
027	AV	8.0	W	B59B	B59B	56			
028	AVS	3.0	Br	B61	B61	66			
029	AVS	3.0	Br	B62	B62	66			
030	AVS	3.0	W	B66	B66	66			
031	AVSS	0.5	R	K48	K48	1			
032	AVSS	1.25	G	K73	K73	1			
033	AVSS	0.5	L	K70	K70	66			
034	AVS	5.0	R	B60	B60	30			
035	AVSS	1.25	R	A50	A50	2			
036	AVSS	0.85	R	A50A	A50A	1			
037	AVSS	1.25	R	K29	K29	1			
038	AVSS	0.5	R	K89	K89	1			
039	AVSS	0.5	L	K50	K50	1			
040	AVSS	0.5	R	K52	K52	1			
041	AVSS	0.85	Br	K15	K15	25			
042	AVSS	0.5	R	K15A	K15A	25			
043	AVSS	0.5	R	K66	K66	1			
044	AVSS	0.85	R	K66A	K66A	1			
045	AVSS	0.5	R	K67	K67	1			
046	AVSS	0.5	R	K38	K38	1			


No.	線路 KIND	線色 COLOR	回路記号 CIRCUIT	端子 TERMINAL	回路記号 CIRCUIT	端子 TERMINAL	回路記号 CIRCUIT	端子 TERMINAL	備考 REMARKS
047	AVSS	0.5	B	K87	K87	1	102		
048	AVSS	0.5	B	K87A	K87A	1	104		
049	AVSS	0.5	B	K85	K85	1	144		
050	AVSS	0.5	B	K86	K86	1	104		
051	AVSS	1.25	L	A30	A30	2	102		
052	AVSS	0.5	W	K14	K14	1	102		
053	AVSS	1.25	L	A15	A15	2	102		
054	AVSS	0.5	R	K24	K24	1	5		
055	AVSS	0.5	L	K63	K63	1	5		
056	AVSS	0.5	G	A12	A12	1	5		
057	AVSS	0.5	B	K77	K77	1	5		
058	AVSS	0.5	B	K77A	K77A	1	5		
059	AVSS	0.5	B	K81	K81	1	6		
060	AVSS	0.5	R	K81A	K81A	1	6		
061	AVSS	0.5	Br	K80	K80	1	6		
062	AVSS	0.5	R	K45	K45	1	36		
063	AVSS	0.5	Y	K85	K85	1	36		
064	AVSS	0.5	W	K39	K39	1	36		
065	AVSS	0.5	B	K74	K74	1	36		
066	AVSS	0.5	P	K39	K39	1	36		
067	AVSS	0.5	B	K21	K21	1	36		
068	AVSS	0.5	G	A28	A28	1	36		
069	AVSS	0.5	L	A29	A29	2	36		
070	AVSS	1.25	O	B42	B42	64	37		
071	AVSS	1.25	O	B42A	B42A	64	37		
072	AVSS	0.5	P	K54	K54	1	37		
073	AVSS	0.5	P	K54A	K54A	1	105		
074	AVSS	0.5	L	K76	K76	1	37		
075	AVSS	0.5	L	K76A	K76A	1	105		
076	AVSS	0.5	R	K23	K23	1	37		
077	AVSS	0.5	G	K20	K20	1	37		
078	AVSS	0.5	Br	K52	K52	1	37		
079	AVSS	1.25	Y	A19	A19	2	37		
080	AVSS	1.25	L	A20	A20	2	37		
081	AVSS	0.5	L	A11	A11	2	38		
082	AVSS	0.5	Br	A61	A61	2	38		
083	AVSS	0.5	P	A61	A61	2	38		
084	AVSS	0.5	G	A26	A26	2	38		
085	AVSS	0.5	B	A25	A25	2	38		
086	AVSS	0.5	W	A25	A25	2	38		
087	AVSS	0.5	Y	K75A	K75A	1	101		
088	AVSS	0.5	L	K53	K53	1	44		
089	AVSS	0.5	L	K53A	K53A	1	101		
090	AVSS	0.5	R	K43	K43	1	48		
091	AVSS	0.5	P	K61	K61	1	48		
092	AVSS	0.5	B	K62	K62	1	48		
093	AVSS	0.5	R	A25	A25	2	38		
094	AVSS	0.5	L	A55	A55	2	38		
095	AVSS	0.5	R	K33	K33	1	37		

名称
NAME HARNESS, A T4
HARNESS, AT4

YANMAR CO., LTD.
POWER SYSTEM OPERATIONS DIV.
コード
CODE 129C88-91120



NOTES OF ALTERNATOR
 IF OTHER ALTERNATOR IS
 INSTALLED, PLEASE
 CONFIRM THAT ALTERNATOR
 HAS DIODE FOR PREVENTION
 OF BACK FLOW CURRENT
 INSIDE.
 IF ALTERNATOR DOES NOT
 HAVE DIODE INSIDE,
 DIODE FOR PREVENTION OF
 BACK FLOW CURRENT SHOULD
 BE INSTALLED BETWEEN IG
 TERMINAL AND IGNSW
 TERMINAL OF ECU.



名称 WIRING DIAGRAM (DPF-CR)
 名称 WIRING DIAGRAM, CIR

YANMAR CO., LTD.
 POWER SYSTEM OPERATIONS DIV.
 コード E3-29C88-0120
 図面サイズ A1 (D)