


Revision: 3

YANMAR CO., LTD.

YANMAR AMERICA CORP.

| V | | N | M | 4 | B |
|---|---|---|---|---|---|
| • | _ | _ | | _ | |

| Item | Lev. (| D Part No. | Description | Quantity | Remarks |
|------|--------|--------------|---|----------|---------|
| 1 | - | | | | |
| 2 | | 119028-12500 | Air Cleaner Assy | 1 | |
| 3 | | 119655-12560 | Element, Air Cleaner | 1 | |
| 4 | | 119028-12560 | Bracket | 1 | |
| 5 | | 119028-12600 | Hose | 1 | |
| 6 | - | 26106-080162 | Bolt, M8 X 1.25 - 16, (Flanged hex head) | 4 | |
| 7 | - | 26013-080162 | Bolt, M8 x 1.25 - 16, (Flanged hex head, captive spring washer) | 2 | |
| 8 | - | 23000-054000 | Clamp 54, Hose | 2 | |



KAC16 - AIR CLEANER KIT

INS-KAC16-0011

PAGE 1 OF 2



YANMAR AMERICA CORP.



Installation Instructions

Hand tighten all bolts and nuts until assembly is completed, then torque according to specifications in Table 1. The numbers in () represent the item numbers.

- 1 Fasten the Air Cleaner Bracket (4) on to the rear face of the cylinder head using M8 x 1.25 16 bolts (6).
- 2. Assemble the Air Cleaner Assembly (2) to the Bracket (4) with M8 x 1.25 16 bolts (7).
- 3. Remove and adjust the Air Cleaner Cover so that the dust collector is orientated in the downward direction between the 4 o'clock and 6 o'clock position.
- 4. Fasten one end of the Air Cleaner Hose (5) to the Intake manifold using Hose Clamp (8). Fasten the other end of the Hose to the Air Cleaner Assembly (2) using the other identical Hose Clamp (8).

NOTE: Comply with torque standards in the table to avoid unexpected damage during installation or in the future.

| Table 1: Tightening Torque | | | |
|----------------------------|-----------|-------------|-------------|
| Diameter x Pitch | Kgf-m | Foot-lbf | N-m |
| M8 x 1.25 | 1.5 ~ 2.9 | 10.6 ~ 20.9 | 14.4 ~ 28.3 |

KAC16 - AIR CLEANER KIT

INS-KAC16-0011

PAGE 2 OF 2